



RESTORE-LITE®
TEMPORARY POWER RESTORATION

Installation and Operation of Cord Sets

The cord set is designed to connect the RESTORE-LITE® unit to the power terminal and neutral.



300 AMP CORD SET WITH FERRULES

COMPATIBLE WITH RESTORE-LITE® UNITS P80070, P80071, P80072, P80079, AND P80079E

- P80066 (8 FT. CORD)
- P80112 (10 FT. CORD)



1

ATTACH EXTERNAL CORD TO RESTORE-LITE® CASE.

Twist lock connection

2

ATTACH CONDUCTOR AND TWIST TO SECURE.

3

READY FOR USE.

Twist to lock Twist to unlock



4

WHEN FINISHED, DISCONNECT ALL CORD SETS FROM RESTORE-LITE® UNIT.

Failure to remove cord sets before transporting unit can result in damage to the cord set and can cause failure.

Always use in accordance with your company practices and procedures.



Visit sncmfg.com to learn more about RESTORE-LITE® or scan the QR code with your mobile device to be taken directly to our website.



www.sncmfg.com | 800-558-3325 | info@sncmfg.com

T0595
05/23