




**RESTORE-LITE®**  
TEMPORARY POWER RESTORATION

# Installation and Operation of Cord Sets

The cord set is designed to connect the RESTORE-LITE® unit to the power terminal and neutral.

**All sets are universal except P80104. P80104 is ONLY compatible with P80100.**



## 300 AMP CORD SET WITH METER HEAD ASSEMBLY

6 O'CLOCK NEUTRAL PLACEMENT (8 FT. CORD)  
• P80023

BROOKS (8 FT. CORD)  
• P80047

RING (8 FT. CORD)  
• P80049

RING (20 FT. CORD)  
• P80052

MARWELL (8 FT. CORD)  
• P80043  
• P80043D (INCLUDES 8 FT. CORD SET WITH FERRULES/P80012)

MARWELL (20 FT. CORD)  
• P80029

MARWELL WITH SLOT (8 FT. CORD)  
• P80113

MARWELL WITH SLOT (8 FT. CORD)  
• P80104 IS ONLY COMPATIBLE WITH P80100



## 1 ATTACH EXTERNAL CORD TO RESTORE-LITE® CASE.


Twist lock connection

## 2 ATTACH CONDUCTOR AND TWIST TO SECURE.

Pig tail provided if required.

## 3 READY FOR USE.

Twist to lock    Twist to unlock



## 4 FINISHING

When finished, disconnect all cord sets from RESTORE-LITE® unit and store the cords in storage bag.

Failure to remove cord sets before transporting unit can result in damage to the cord set and can cause failure.

Always use in accordance with your company practices and procedures.



Visit [sncmfg.com](http://sncmfg.com) to learn more about RESTORE-LITE® or scan the QR code with your mobile device to be taken directly to our website.



[www.sncmfg.com](http://www.sncmfg.com) | 800-558-3325 | [info@sncmfg.com](mailto:info@sncmfg.com)

T0596  
05/23